


# FZ scale cable configuration


Standard scale cable length {  
FZ620Ex ~ FZ200K1GEx : 1m  
FZ150K1GFEx ~ FZ300K1GFEx : 5m

(scale cable = cable between weighing cell and indicator)

## Standard configuration



## Optional extension : 5m or 10m extensions are available



# FZ power supply cable configuration

Standard power supply cable length : 5m for all models  
(power supply cable = cable between indicator and power supply box)

## Standard configuration

Indicator

Standard power supply cable (5m)

Power supply box




## Optional replacement cable : from 10m up to 70m (per 10m)

Indicator

**[Important]** Optional cable replaces standard cable,  
not additionally connected to standard cable.

Power supply box



Longer cable than 70m is available as custom-made option.  
Please contact local distributor for detail.