


FS scale cable configuration


Standard scale cable length { FS620 ~ FS200K1G : 1m
FS150K1GF ~ FS300K1GF : 5m

(scale cable = cable between weighing cell and indicator)

Standard configuration



Optional extension : up to 30m (per 5m)



* No extension in power supply part (power cable pf FS-OX is 5m.)